



TECHNICAL ARTICLE

Cockling of Paper Release Liners

The summer is upon us and with it come thoughts of the beach, barbeques, and baseball. For manufacturers and users of pressure-sensitive tapes, it also brings concerns about cockling liners. You know the old saying, "it's not the heat, it's the humidity?" In our business, this is a very accurate statement. While we cannot stop the forces of nature, we can offer the rationale behind cockling and potential ways to deal with the problem.

What is cockling?

To anyone who has manufactured or used pressure-sensitive tapes with a silicone-coated, densified kraft release liner, cockling is a familiar sight, even if you were unaware of the technical term we use to describe it. Paper, by its very nature, is an absorptive medium. In high humidity, as typically experienced in the summer months, paper will absorb moisture from the atmosphere. As a result, the paper swells - it grows in all three dimensions resulting in what looks like waviness or wrinkling, which is referred to as "cockling".



Close up view of cockled paper

Rolls of tape showing the cockling phenomenon

All paper-based products will cockle to some degree; some visibly, others more discreetly. Densified kraft will cockle quite visibly, as the pictures above illustrate. There are several paper coatings, which can be employed to alleviate this. Poly-coated liners have a layer of polyolefin (plastic) coated on both sides of the base paper. This plastic layer helps to encapsulate the paper and prevent it from drawing in moisture. Using higher basis weight paper, coupled with a poly-coating layer can further protect against cockling. However, these steps do not eliminate cockling all together.

Why is cockling a problem to me?

Because the paper is growing in all dimensions and the pressure-sensitive tape is not, there is the potential for creasing and wrinkling during the lamination process resulting in scrap. To avoid this potential, an enduser may choose to unwind a couple wraps of tape to reveal non-cockled product. We understand that no one likes to waste material! Mounting surfaces, which are pre-laminated with tape can cockle prior to the secondary laminating process. Again, this cockling can lead to creases or wrinkles in the secondary laminating process.

> Berry Global Inc. | 1852 Old Country Rd. Riverhead NY 11901 | 631-727-6000 www.adchem.com | www.berryglobal.com

Data presented are typical properties taken from a limited number of production runs and should not be used for specification purposes. Berry Global makes no warranty, expressed or implied, and specifically disclaims and disavows any implied warranty of merchantability and of fitness for a particular purpose. Accordingly, all products are sold with the understanding that purchasers will be solely responsible for determining the suitability of the materials for any purpose.





TECHNICAL ARTICLE

How do I deal with cockling?

As a partner in your process, we continuously seek ways to offer solutions to the issues you encounter. Having worked through the various ways that cockling can affect your operations, we offer the following as a means to assist you in minimizing losses and help you to avoid creasing and wrinkling. Cockling can be thought of as an "outer surface phenomenon," In truth, the paper wound tightly within a roll is picking up moisture and changing dimensionally, but not to the point at which it becomes cockled. If we keep this in mind when handling the tape in the summer months or in environments with high humidity, several options present themselves including:

- Proper Storage: Rolls of tape with paper liners should be stored in a cool dry environment. They should be protected from dirt, extreme temperatures and humidity, and damage.
- Protection: Plastic wrap around each roll, including both ends, will help to keep the moisture from getting to the paper.
- Maintenance: When a laminating job is complete, the remaining roll should be wrapped in plastic, even if it is still up on the machine.
- Any product already threaded through the laminator will be unprotected and may need to be discarded if it develops severe cockling prior to the next job.
- Pre-laminated parts (foam sheets, pre-coated graphic arts mounting boards, etc.) should be protected from humidity by storing them in a controlled environment or by wrapping them in plastic.

In some cases, even a small degree of cockling is unacceptable for a given application. In these situations, it may become necessary to seek alternate liner solutions such as:

- Poly-coated liners, which offer a degree of protection from cockling.
- Board is another option. Although 12-pt board is a paper based liner, its heavy basis weight and a layer of poly-coating on both sides virtually eliminates cockling.
- In some cases, a film liner may be an answer. Plastics are not as absorptive as paper and therefore, not susceptible to cockling.

We at Berry are providing this information to you, valued customer, so you better understand the nature of the phenomenon and the simple ways to remedy it. We encourage you to share this information with your operations personnel, so they know the options that can be taken. We further encourage you to share this information with your sales force and end customers.

Remember, in the summer, it is not the heat, it is the humidity.